


redi your way®


REDI YOUR WAY® SHOWER PAN - INSTALLATION INSTRUCTIONS

These instructions are exclusively for Redi Your Way (black shower pans). If you have received a yellow (Tile Redi®) shower pan please visit tileredi.com/knowledge-center for the correct instructions.




TOOLS REQUIRED






1. Frame out shower stall area to shower pan dimensions. The bore hole needs to be a minimum 6", but not more than 7" diameter opening*. Ensure that the shower pan subfloor is level, and that the walls are level, plumb, and square. Place the square in corners to ensure they are square and straight. All walls and framing must be plumb prior to proceeding. The floor must be level within 3/8". Sweep up any debris from subfloor.

Redi Free® Installation: For a proper barrier free pan installation, subfloor must be recessed (in accordance with local codes) to the depth of the front lip of pan. Waterproof the seam between shower pan and subfloor with a waterproofing tape and a liquid-applied membrane.



2. To ensure a perfect fit, test fit shower pan drain housing into subfloor bore hole. Make sure the shower pan is aligned properly and fits snugly against the shower frame studs on all sides and corners. Ensure that the pan is level on the floor. There should be no movement or bulge.



DO NOT NAIL OR SCREW INTO THE PAN. DO NOT SAND, CUT, OR MAKE ANY CHANGES/MODIFICATIONS TO THE SURFACE OF THE SHOWER PAN WHATSOEVER.



3. This step depends on whether there is access to the drain connection from below the subfloor:

a. If there is access from the subfloor below, then cut a section of PVC drain pipe which is long enough to extend below the subfloor and easily make a connection to the waste water pipe. Brush primer and PVC adhesive (we recommend Oatey Hot Medium Blue Lava PVC cement or Oatey Medium Gray PVC cement) on the inside of the drain and outside of the cut drain pipe and quickly insert into drain connection. Then be sure the drain pipe extends far enough below the subfloor so it can be conveniently connected to the waste water pipe following the installation.

b. If there is no access from the subfloor below, then make sure the drain pipe stubbed up from the subfloor is adjusted to a height sufficient to fit properly into the shower pan drain connection (approximately 3/8" for circular drains and 1/2" for trench drains below the substrate floor). Brush primer and PVC adhesive (as described above) on the drain pipe stubbed up from the subfloor, then quickly insert the stubbed-up drain pipe properly into the shower pan drain.




4. Using a 1/2" square notch trowel form a 1/2" thick modified thin-set bed on the entire shower enclosure substrate, making sure to apply the modified thin-set all the way to the edge of the drain bore hole.



DO NOT PLACE THIN-SET DIRECTLY ON A WOOD OR GYP-CRETE SUBSTRATE. FIRST, WATERPROOF THE SUBSTRATE WITH A FLUID APPLIED WATERPROOFING MEMBRANE, OR NO. 15 OR NO. 30 ROOFING PAPER SO THE WOOD DOES NOT ABSORB THE WATER FROM THE THIN-SET.

*Creating a bore hole larger than 7" would void any warranty.


**Pipe adhesion code standards can vary. Please check local plumbing codes.




5. Place the pan on the thin-set bed and apply pressure or wiggle the pan a little to make sure the thin-set spreads out evenly under the pan so the pan makes proper contact with the modified thin-set. This process will ensure that the modified thin-set will fill in the footprint of the pan.




6. Using the level, ensure that the pan is level left to right, and front to back along the splash walls. Also make sure the pan is level left to right along the curb.



DO NOT USE THE INSIDE OF THE PAN AS AN INDICATOR SINCE THE PAN IS PRE-PITCHED. DO NOT STEP INTO THE SHOWER PAN ONCE THE SHOWER PAN HAS BEEN SET AND LEVELED UNTIL THE THIN-SET HAS CURED COMPLETELY.



7. Install Redi Wall boards or other shower backer board and waterproofing in accordance with the manufacturers instructions and the standards established by the Tile Council of North America. Seal and waterproof joints between Redi Wall or other backer board and the shower pan splash walls using Redi Flash®, Redi Sealant™, or 100% silicone. If you are not using Redi Wall and Redi Sealant, it is recommended to use a membrane or liquid applied waterproof product in addition to the Redi Flash or 100% silicone. Allow the mortar bed to dry in accordance with the instructions of mortar manufacturer prior to wall system installation.



8. You are now ready to tile to the shower enclosure. Only Rapid Set thin-set/tile mortar or any type of modified thin-set/tile mortar should be used to lay tile on the pan. Adjust the height of the drain as necessary to accommodate the flooring covering.

⚠ CALIFORNIA PROP 65 WARNING: This product contains one or more chemicals, including Chromium, known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov

436 East 36th Street, Charlotte, NC 28205
800.232.6156 | sales@tileredi.com

www.tileredi.com

Tile Redi® trademarks and logos are owned by and the Intellectual Property of Tile Redi, LLC.
©2024 Tile Redi, LLC. All Rights Reserved.

PATENT: www.TileRedi.com/PatentMarkings